

THINKTOOL Reader Indian Version

5 inches Automotive Diagnostic Tool



Plug and Play



The Most
Economic Tool



Lifetime
Subscription




Developed by SCANTOOLS SOLUTIONS

Main Function

THINKTOOL Reader 7 is a 5 inches android system diagnostic tool produced by THINKCAR. Offers lifetime subscription for mechanics, repair shops and DIY.



Mechanics




Repair shops



DIY

OE-Level Diagnostics

90% car makes in the market have 7 systems, ABS,SRS,ECM,TCM,BCM,AC and IC. THINKTOOL Readers 7 is developed be more cost effective and support all the 7 systems diagnostics.



Full OBDII/ EOBDII Function

THINKTOOL Reader7 supports full OBD II and EOBDII functions such as read and clear codes, freeze frame, live data stream, O2 sensors, EVAP system, On Board Monitor etc. The real time live data stream can be intuitive shown on the screen, which will help technicians to adjust relevant parameters.

Read Codes



Clear fault code



View Freeze Frame

Live data stream



O2 Sensor Test



EVAP System Test

DTC Lookup & Lifetime Free Update

The built-in DTC library brings quick DTC definition lookup and there's more than 3000 DTC definitions. What's more, it has lifetime free automatic update and there is no more additional cost.

DTC Lookup



Lifetime Free Update

THINKTOOL Reader 7 is compatible with vehicles after 1996 with OBD II port and supports CAN, ISO9141, KWP2000, J1850 PWM, J1850 VPW. Covers 98% car makes worldwide including American cars, Asian cars, Chinese cars, European cars.



Cover 98% passenger car makes globally

98%





Multilingual Support

THINKTOOL Reader 7 supports English, French, German, Spanish, Portuguese, Russian, Japanese and Italian languages.

Specifications



System
Android 6.0



ROM
1G



Storage
16G



Screen
size 5 inches



Wireless
WiFi
(802.11b/g/h)



Certificates
CE 、 FCC、 ROHS



Working
Temperature
0°C-50°C



Storage
Temperature -20°C
~60°C



In-build
Chip CORTL A7
1.3GHz

28 Maintenance Reset Function

THINKTOOL Reader 7 support 28 maintenance reset function includes Oil Reset, AFS (headlamp) Reset, Windows Calibration, Steering Angle Reset, Seat Calibration, Battery Matching, Tyre Reset, ABS Bleeding, L Throttle Adaption, A/F Reset, Sunroof Initialization, DPF Regeneration, EGR Adaption, Immobilize Reset, Co Reset, Transport Reset, Airbag Reset, ODO Reset, Gear Learning, Adblue Reset, SUS Reset, NOX Reset, A/T Reset, Basic TPMS Reset and etc.



Oil Reset



Elec. Throttle Rlm



Brake Reset



Immo



SAS Reset



Bleeding



AFS Reset



Injector



DPF Reg.



TPMS Reset



Sun Roof



Sus Reset



Gear Learn



ODO Meter



Airbag Reset



Stop/Start Reset



EGR Adaption



A/F Reset



Seats Calibration



Language Change



Tyre Reset



NOx Sensor Reset



Windows Calibration



Coolant Bleed